
# DALI volt-free relay zc-relay

# zencontrol



### Product range

Order code	Description	
zc-relay	DALI volt-free relay, DIN mount	


## **Specifications**

Supply voltage	220 - 240 V ~ 50 Hz	
Control system	DALI	
DALI line current	2 mA	
Relay type	Non-latching normally open	
Output type	Dry-contract volt-free relay	
Output load AC	10 A resistive & 6 A inductive ♣	
Output voltage rating AC	0 - 240 V ~ 50 Hz	
Output load rating DC	0 - 25 V 3 A resistive & 25 - 240 V 200 mA resistive &	
Min. rated relay operations	40 000	
Max. operations per hour	360	
Wiring	1 - 4 mm <sup>2</sup> Strip 6 - 7 mm	
Operating temperature	0 to 45°C	
Operating humidity	0 to 85 %	
Material	PC	
Classification	Class II	

### **Dimensions**

Mounting options	DIN rail mount (35 mm)	
Dimensions	92.5 / 36 / 62 mm	
A BANGOLIGA	36 50 36	92.5

### System overview




### Installation

Remove the product from the box and inspect it for any damage. If you believe the product to be damaged or otherwise unsound, *do not* install the product. Please pack it back into its box and return it to the place of purchase for replacement.

### If the product is satisfactory, proceed with the installation:

- 1 Ensure safety warnings are adhered to.
- 2 Mount the DALI relay on DIN rail inside a mains rated enclosure as shown in *fig 1*. To remove from DIN rail, release the clip mechanism with a flat blade screw driver, as per *fig 2*.
- 3 Wire the DALI relay as per the wiring diagram in fig 3.

**Note** each DALI relay must have an appropriate MCB to protect the load circuit.



# Safety information

- This product must only be installed by a licensed electrician.
- Before commencing installation turn off and isolate the electrical supply.
- There are no user serviceable parts, attempting to service any part of the product will void the warranty
- DALI is not SELV and as such should be treated as LV.
- As the installer, it is your responsibility to ensure you comply to all relevant building and safety codes. Refer to application standards for the relevant rules.
- When the installation is complete, leave this manual with the building's owner for future reference.





# Wiring diagram



Wire preparation



# **Notice**



For more information on compliant software see our website **zencontrol.com** 

zencontrol.com © zencontrol